



# Replaces Toro Groundsmaster 3320

## Parts

62in Rotary Deck - Model 30376  
Caster Wheels



All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Toro Groundsmaster 3320

## Parts

62in Rotary Deck - Model 30376  
Caster Wheels



| Item No                      | R&R Part No.        | OEM Part No.         | Description                           | Qty Req | Order Quantity |
|------------------------------|---------------------|----------------------|---------------------------------------|---------|----------------|
| <b>Tires &amp; Wheels</b>    |                     |                      |                                       |         |                |
| 31                           | <b>R93-9938</b>     | 86-0020,<br>93-9938  | Wheel Assy - Castor - Pneu 8x3.50-4   | 2       |                |
| 32                           | <b>R93-9939</b>     | 93-9939,<br>98-2877  | Tire - 8x3.50-4 (4 Ply) Sm Pneu       | 2       |                |
| 32                           | <b>R150615</b>      | 136-4424             | Tire - Foam Filled 8-3.5 x 4 Sm 4 Ply | 2       |                |
| 33                           | <b>R100-5832</b>    | 100-5832             | Tube - Castor Wheel 2.80/2.50-4       | 2       |                |
| 33                           | <b>R68-8950</b>     | 68-8950              | Tube - Castor Wheel 9x3.50-4 TR87     | 2       |                |
| <b>Other Parts Available</b> |                     |                      |                                       |         |                |
| 50                           | <b>R69-6860</b>     | 69-6860              | Washer - 1/8 - Caster Wheel           | 4       |                |
| 51                           | <b>R104-0762-01</b> | 104-0762-01          | Caster Fork                           | 2       |                |
| 52                           | <b>R69-6470</b>     | 69-6470              | Bushing - Flanged                     | 4       |                |
| 53                           | <b>R69-1510</b>     | 69-1510              | Spacer - 1/2 Caster Fork              | 10      |                |
| 54                           | <b>R92-9727</b>     | 92-9727              | Cap Assy - HOC                        | 2       |                |
| 55                           | <b>R92-8861</b>     | 92-5582,<br>92-8861  | Cap - HOC                             | 2       |                |
| 56                           | <b>R92-9726</b>     | 92-9726              | Spring - Compression                  | 2       |                |
| 57                           | <b>R92-5583</b>     | 92-5583              | Washer- Cap                           | 2       |                |
| 58                           | <b>R92-5581</b>     | 92-5581              | Ring - Retaining                      | 2       |                |
| 60                           | <b>R93-4242</b>     | 93-4242              | Plate - Caster Wheel                  | 2       |                |
| 61                           | <b>R32128-16</b>    | 32128-16             | Locknut - 5/16-24 Flanged Top         | 8       |                |
| 62                           | <b>R95-2741</b>     | 137-5552,<br>95-2741 | Rim - Wheel Half w/o Valve Hole       | 2       |                |
| 63                           | <b>R93-4239</b>     | 93-4239              | Rim - Wheel Half w/Valve Hole         | 2       |                |

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Toro Groundsmaster 3320 Parts

62in Rotary Deck - Model 30376  
Caster Wheels



| Item No | R&R Part No.     | OEM Part No.          | Description                    | Qty Req | Order Quantity |
|---------|------------------|-----------------------|--------------------------------|---------|----------------|
| 65      | <b>R93-5980</b>  | 93-4238,<br>93-5980   | Hub Assy - w/o Bearings/Spacer | 2       |                |
| 66      | <b>R93-4241</b>  | 93-4241               | Spacer - Caster Wheel          | 2       |                |
| 67      | <b>R93-4237</b>  | 93-4237               | Bearing                        | 4       |                |
| 67      | <b>R108-9017</b> | 108-9017,<br>120-3366 | Bearing-Stainless              | 4       |                |
| 68      | <b>R3296-53</b>  | 3296-53               | Locknut - 5/8-11 ESNA Yellow   | 2       |                |
| 69      | <b>R327-24</b>   | 327-24                | Bolt - Hex HD 5/8-11 x 6       | 2       |                |

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.